


5.6.Connection of AV Output

Connect the yellow port of the AV output head to video jack, the white port to the left audio plug, the white port to the right audio plug. Then insert the AV head into the AV/OUT jack.




⚠ Notice

- 1.The AV output function is available when using DVB function only.
- 2.OSD language is locked as English when using AV function.


5.7.Connection of VGA input:

Just insert the connect cord to the VGA port of PC, and tighten the screws to keep good contact. Then plug the another end of the cord to the VGA port of the TV set and tighten the screws as the same.



■ Basic operation methods of TV set

1. Connect with power supply and turn on the power switch. In normal status, the power light is green. If the light is red, press the Power key to turn on the TV set.
2. Pull out telescopic antenna.
3. Press CH-/CH+ to choose the desired channel.
4. Adjust the sound volume of the TV.



- 1.Remote Sensor
- 2.Menu
- 3.DVB confirm OK
- 4.Volume decreases
- 5.Volume increases
- 6.Change in the order of 3, 2, 1, ...
- 7.Change in the order of 1, 2, 3, ...
- 8.Power on (green)/standby (red) indicator
9. ON/OFF DVB/ATV/VGA/AV Shift
Press and hold for 3 seconds to turn off, and press again to turn on.


⚠ Notice

- 1.ON/OFF/DVB/ATV/VGA/AV shift: press momentarily to shift DVB/ATV/VGA/AV, press and hold for 3 seconds to turn off the TV set, and press again to turn it on.
- 2.The OK key on panel is available only when DVB function is operating.


6. DVB-T Menu Operation

6.1. DVB-T digital TV receiver automatic installation


First Time Installation.
(The Program list does not exist.)



Cancel first time installation



Select country
(Receiving the local system)



The system will automatically start the First Time Installation when the TV is turned on. Please set up the installation as illustrated. The system may not start the First Time Installation at status as below:

- 1.The First Time installation has been set before.
 - 2.The Program list is not empty.
- If you want to start the First Time Installation again, please do as below:
- 1.Delete all channels in the program list.
 - 2.Set Factory Default at additional option setting.

Notice:
You need to enter PIN number, to delete all programs; enter search or start the first time installation while parental control lock is in ON status. But in OFF status, no PIN is required. After returning to the factory default, the parental lock is set in OFF status.

Press VOL+/VOL- to move the cursor to YES or No item. Press OK key to confirm.

YES: Start First Time Installation.
NO: Cancel First Time Installation.

Press VOL+ or VOL- key on the remote control to select Country at the standard of local TV system. Press CH+ or CH- key on the remote control to move the cursor to select other item.